

## Savant DigiFlow 8300T-88, Liter Model, LCD Display Flow Monitor

---

SAVANT ELECTRONICS INC.

2088-3, Sec.1, Huanzhong road, Taichung 40761, Taiwan

Tel : 886 4 2425 5578 Fax : 886 4 2425 0396

Email : [savantco@ms65.hinet.net](mailto:savantco@ms65.hinet.net)

Website : [www.digisavant.com](http://www.digisavant.com)

### Features :

- Filter capacity monitor, programmed from 1 – 99,999 liters
- End of capacity alert
- Minus counting
- Battery operated, 2 AA alkaline batteries
- Low battery power alert



### Application :

- ✓ Water treatment system
- ✓ Agriculture water supply system
- ✓ Industrial water treatment system

### 1.0 Electrical :

Operating Voltage : 3 DC Volts

Operating Current : 1.0 mA (work), 0.015 mA (sleep)

### 2.0 Application :

Mounting Method : Vertical or Horizontal

Flowing Direction : One direction

Flow Rate : 3 - 100 liter/minute

Reading : 1 – 99,999 liters

Flow media : Water

### 3.0 General :

Temperature : 0 to 80 °C (no freezing)

Working pressure : Max. 1 MPa

Burst pressure : 3 MPa

Weight : 190 g

Accuracy : +/- 7 %

Connection : 1" BSP male (NPT male option)

Materials : Sensor housing : PA6 with 50% glass fiber

Turbine : Plastic magnet

Stick of turbine : #304 stainless steel (option : ceramic)

## 4.0 Operation Guide

### 1. Install batteries

Slide off the cover case of the battery room, and put into two AA alkaline batteries. Then slide the cover case back. The power of two AA alkaline batteries could last for two years.

### 2. Connecting fitting

The thread specification of the DigiFlow 8300T-88 is 1" BSP male.

### 3. Programming monitoring capacity

Press "PROG" button, the "ProG" blinks on the LCD. Then press "RESET" to choose the right value to save from the right digit. Once the value is chosen, press "PROG" button to save the value and goes to the next digit. Repeat the above procedure to program the values for five digits from right to left. The maximum monitoring capacity for the DigiFlow 8300T-88 is

9999.9 m<sup>3</sup>(x 1000 liters), or 9999.9 x 1000 gallons (Gallon model). If there is no input for one minute during the programming procedure, the programming procedure will be terminated and goes back to the original status.

### 4. Operating

The DigiFlow 8300T-88 automatically turns on and displays the remaining capacity when there is water flowing through the sensor. And it automatically turns off in 10 seconds when there is no water flowing.

### 5. End of capacity alert

The DigiFlow 8300T-88 generates an audible alert and the digits on the LCD blinks when its remaining capacity reaches zero or minus.

### 6. Resetting

Press the "RESET" button for three seconds, the "rESEt" on the LCD blinks twice, and the remaining capacity is reset to the original programming value.

### 7. Low battery power alert

When the battery power is low, the DigiFlow 8300T-88 generates an audible alert and the empty battery symbol on the right-up corner of the LCD blinks. The alert status will be released when the batteries are replaced by new batteries. The data of the last status will be memorized and stored back.